

Bill of Materials Listing

TransArctic Canada Inc.

4/25/2017
Page 1 of 1

Product Number	Description	Date	Weight	Uof M	Yield
Line	Component Prod#	Unit	Qty		
KMC61972	Mt Kit, ISB, 6.7L, BBCV, TM-31, '17	9/24/2013	44.35		0
10	BEL61486	Belt, 6gr, 1486mm (58.5") (5060585)	each	1	
20	BMC67063	Bkt, Alt, Bar, ISB, F400, BBCV, '10	each	1	
30	BMC67069	Bkt, Angle, Brace, Hanger, Hose, 2010	each	2	
40	BMC67071	Bkt, Main, 6.7L, ISB, TM-55, BBCV,'10	each	1	
50	BMC67104	Bkt, Adapter, PL, ISB, TM-31, BBCV, '13	each	1	
70	BMC67105	Bkt, Shroud, Cover, ISB, TM-43/31,'10-'13	each	1	
75	BMC67107	Bkt, Spacer, PI, TM-65/55/43, .06", ALUM	each	2	
80	BMC67126	Bkt, Main, V Weldmt, TM-65/55/43/31, '13	each	1	
90	BMZ00028	Bkt, Universal Hose & Cable	each	1	
100	BMZ00029	Bkt, Univer, Hose/Cable, MT, U/S Chassis	each	1	
110	CLP20001	Clamp, Gear, #20, 3/4-1 3/4 (19/44mm), S	each	2	
115	SCD25410	Spacer, Col, Drl, 25.4mm x 25.4o x 10.3i	each	4	
120	TEN80001	Tenr, HD Spring, BackSide, CW (89200D)	each	1	
130	KBC61971	Bag Kit, Fasteners, KMC61971/72	each	1	

NOTES:

- 1) The "TURBO TUBE" is rotated "END TO END" when re-installing it back onto the bus.
- 2) Belt runs in the "FRONT 6 grooves" of the compressor pulley.
- 3) Use blue "Loctite" when installing the (2) Alternator bolts.




Bill of Materials Listing

TransArctic Canada Inc.


4/25/2017
Page 1 of 1

Product Number	Description	Date	Weight	Uof M	Yield
Line Component Prod# Description	Bin	Unit	Qty		
KBC61971	Bag Kit, Fasteners, KMC61971/72	4/8/2011	2.29		0
10 BTC08030	Bolt, Hex, 8 x 1.25 x 30mm, 10.9, Plt,FT	each	2		
30 BTC10025	Bolt, Hex, 10 x 1.5 x 25mm, 10.9, Plt	each	7		
40 BTC10035	Bolt, Hex, 10 x 1.5 x 35mm, 10.9, Plt,FT	each	1		
45 BTC10055	Bolt, Hex, 10 x 1.5 x 55mm, 10.9, Plt,FT	each	4		
50 BTC10070	Bolt, Hex, 10 x 1.5 x 70mm, 10.9, Plt	each	4		
55 BTC10090	Bolt, Hex, 10 x 1.5 x 90mm, 10.9, Plt	each	1		
60 BTC10140	Bolt, Hex, 10 x 1.5 x 140mm, 10.9, Plt	each	2		
90 CSF08031	Capscrew, FH, 8 x 1.25 x 30mm, 10.9,Plt	each	2		
100 CSF10026	Capscrew, FH, 10 x 1.5 x 25mm, 10.9,Plt	each	4		
110 NTA10000	Nut, Hex, 10 x 1.5, 8.8, Plt	each	2		
120 WFA08000	Washer, Flat, 8mm, 8.8, Plt	each	2		
130 WFA10000	Washer, Flat, 10mm, 8.8, Plt	each	19		
150 WLA08000	Washer, Lock, 8mm, 8.8, Plt	each	2		
160 WLA10000	Washer, Lock, 10mm, 8.8, Plt	each	18		

8 7 6 5 4 3 2 1



SECTION A-A



ISOMETRIC VIEW

ITEM	QTY	U/M	PART NUMBER	DESCRIPTION
27	18	EACH	WLA10000	WASHER, LOCK, 10mm, 8.8, PLT
26	2	EACH	WLA08000	WASHER, LOCK, 8mm, 8.8, PLT
25	19	EACH	WFA10000	WASHER, FLAT, 10mm, 8.8, PLT
24	2	EACH	WFA08000	WASHER, FLAT, 8mm, 8.8, PLT
23	1	EACH	TEN80001	TENR, HD SPRING, BACKSIDE, CW
22	4	EACH	SCD25410	SPACER, COL, DRL, 25.4mm x 25.4o x 10.3i
21	2	EACH	NTA10000	NUT, HEX, 10 x 1.5, 8.8, PLT
20	4	EACH	CSF10026	CAPSCREW, FH, 10 x 1.5 x 25mm, 10.9, PLT
19	2	EACH	CSF08031	CAPSCREW, FH, 8 x 1.25 x 30mm, 10.9, PLT
18	2	EACH	CLP20001	CLAMP, GEAR, #20, 3/4-1 3/4 (19/44mm)
17	2	EACH	BTC10140	BOLT, HEX, 10 x 1.5 x 140mm, 10.9, PLT
16	1	EACH	BTC10090	BOLT, HEX, 10 x 1.5 x 90mm, 10.9, PLT
15	4	EACH	BTC10070	BOLT, HEX, 10 x 1.5 x 70mm, 10.9, PLT
14	4	EACH	BTC10055	BOLT, HEX, 10 x 1.5 x 55mm, 10.9, PLT
13	1	EACH	BTC10035	BOLT, HEX, 10 x 1.5 x 35mm, 10.9, PLT
12	7	EACH	BTC10025	BOLT, HEX, 10 x 1.5 x 25mm, 10.9, PLT
11	2	EACH	BTC08030	BOLT, HEX, 8 x 1.25 x 30mm, 10.9, PLT
10	1	EACH	BM200029	BKT, UNIVER, HOSE/CABLE, MT, U/S CHASSIS
9	1	EACH	BM200028	BKT, UNIVERSAL HOSE & CABLE CLAMP
8	1	EACH	BMC67126	BKT, MAIN, V Weldmt, TM-65/55/43/31, '13
7	2	EACH	BMC67107	BKT, SPACER PL, TM-65/55, '06, ALUM
6	1	EACH	BMC67105	BKT, SHROUD, COVER, ISB, TM-43/31, '10-'13
5	1	EACH	BMC67104	BKT, ADAPTER, PL, ISB, TM-31, BBCV, '13
4	1	EACH	BMC67071	BKT, MAIN, 6.7L, ISB, F400, BBCV, 10
3	2	EACH	BMC67069	BKT, ANGLE, BRACE, HANGER, HOSE, 2010
2	1	EACH	BMC67063	BKT, ALT, BAR, ISB, F400, BBCV, '10
1	1	EACH	BEL61486	BELT, 6Gr, 1486mm (58.5") (5060585)

BILL OF MATERIALS
TRANSARCTIC INC.

NOTES:
1) USE SERVICABLE THREADLOCKER ON ALL FASTENERS TO ENGINE COMPONENTS AND TORQUE ALL BOLTS TO S.A.E. SPECIFICATIONS.
2) SEE "TRANSARCTIC A/C COMPRESSOR MOUNT INSTALLATION DISCLAIMER".

REV	ECN	DESCRIPTION	DATE	BY	APPROVED
0		RELEASED TO PRODUCTION	04/25/17	VAL JAKOWIEC	
				James Stewart	4/25/2017
				DALE MASON	4/25/2017
				James Stewart	4/25/2017

DRAWN: Jose Rodriguez 4/25/2017
CHECKED: Val Jakowiec 4/25/2017
DATE: 4/25/2017
BY: James Stewart
APPROVED: Dale Mason 4/25/2017
APPROVED: James Stewart 4/25/2017

THIS DRAWING CONTAINS PROPRIETARY CONFIDENTIAL INFORMATION OWNED BY TRANSARCTIC CANADA INC. THE DOCUMENT AND THE INFORMATION IN IT ARE NOT TO BE USED, DISCLOSED OR REPRODUCED WITHOUT EXPRESS WRITTEN PERMISSION OF THE COMPANY.


UNSPECIFIED TOLERANCES:
ONE DECIMAL PLACE (X1) IN .001
TWO DECIMAL PLACE (X10) IN .002
THREE DECIMAL PLACE (X100) IN .005
FRACTIONS: 16, 32, 64



DRAWING UNIT OF MEASURE: MM (INCH)
SCALE: 1:4


MT KIT, ISB, 6.7L, BBCV, TM-31, '17
DWG NO: KMC61972
REV: 0



THIRD ANGLE PROJECTION

8 7 6 5 4 3 2 1









TransArctic A/C Compressor Mount Installation Disclaimer

All compressor mounts should be installed by qualified and trained personnel using proper tools and equipment in safe working conditions following industry standard guidelines for motor vehicle service and repair.

The installer of any compressor mount purchased from TransArctic must undertake all responsibility of issues arising from that compressor bracket being installed on any vehicle. As well as insure that a **proper and sufficient ground** is established between the compressors' clutches and the vehicle's engine. Mount functionality, operation and durability can all be compromised by an incompetent installation.

Due to the many different situations, parameters and application criteria, which are beyond the compressor mount manufacturer's control, TransArctic does not warrant design, durability, or operational functionality of any compressor mount improperly installed by another party.

With no implied guarantees it is the mount installer's strict responsibility to determine safety and functionality, of the compressor mount, at the time of installation.

Please contact TransArctic with any issue arising from installation so we may better improve the product. If you have any reservations about the compressor mount integrity contact TransArctic immediately at 1-877-COLD-AIR.

Mark OEM tensioner location

Install Kit

Check for Interferences

Check to ensure that the proper OEM tensioner orientation is maintained

Run engine with A/C system engaged for at least 10 minutes to run in belt

Check OEM tensioner orientation and adjust as required

Responsabilidad limitada de TransArctic en la instalación del soporte del compresor

Todos los soportes de los compresores deben ser instalados por personas calificadas y entrenadas, usando para ello los equipos y herramientas necesarios para esta labor en buenas condiciones y según las normas y guías para el servicio y/o reparación de motores de vehículos.

El instalador de los soportes comprados en TransArctic asume toda la responsabilidad de cualquier problema que surga en el soporte del compresor al vehículo; de igual manera es responsable que el cable a tierra sea conectado entre el embrague del compresor y el motor del vehículo.

Se advierte que el buen funcionamiento y la durabilidad del soporte pueden ser comprometidos por defectos en su instalación.

Debido a las diversas situaciones que se puedan presentar fuera del control del fabricante, TransArctic no garantiza el diseño, la durabilidad o el correcto funcionamiento de cualquier equipo inapropiadamente instalado por terceros.

Esta sobreentendido que el Instalador del montaje del compresor es estrictamente responsable de la seguridad y funcionamiento del equipo en el momento de la instalación.

Si tuviera algún problema o duda acerca de la instalación del soporte del compresor pongase en contacto inmediatamente con TransArctic al teléfono 1-877-COLD-AIR de modo que podamos mejorar nuestro producto.

Note la ubicación del medidor de tensión OEM

Instale el equipo

Controlar si hay interferencias.

Asegurese que el medidor de tensión mantenga la orientación justa.

Encienda el motor por lo menos 10 minutos con el sistema A/C enganchado para que la correa corra

Controle la orientación justa del medidor de tensión y ajuste a las condiciones requeridas del fabricante